



AC800 Series Intelligent Mechanical Programmable Controller User Guide



Industrial
Automation



Intelligent
Elevator



New Energy
Vehicle



Industrial
Robot



Rail
Transit



Data code 19010617B07

Preface

Introduction

The AC800 high-performance intelligent mechanical controller is a high-performance multi-axis motion controller based on the Intel X86 processor hardware platform and complies with the PLCopen specification. It uses EtherCAT bus to achieve multi-axis servo control and is especially suitable for the control of high-speed production equipment and large-scale equipment in advanced manufacturing.

This guide introduces the installation and wiring of the product, including mechanical installation, electrical installation, and operation instructions.

Standard

The following table lists the certifications, directives, and standards that the product may comply with. For details about the acquired certificates, see the certification marks on the product nameplate.

Certification	Directive		Standard
CE Certification	EMC Directive	2014/30/EU	24 VDC products: EN 61131-2 220 VAC products: EN 61131-2 EN 61000-3-2 EN 61000-3-3
	LVD Directive	2014/35/EU	EN 61010-1 EN 61010-2-201
	RoHS Directive	2011/65/EU amended by (EU) 2015/863	EN IEC 63000
UL/cUL Certification	-	-	UL 61010-1 UL 61010-2-201 CAN/CSA-C22.2 No. 61010-1 CSA C22.2 NO. 61010-2-201
KCC Certification	-	-	-
EAC certification	-	-	-
UKCA Certification	Safety Regulations	Electrical Equipment (Safety) Regulations 2016	EN 61010-1 EN 61010-2-201
	EMC Regulations	Electromagnetic Compatibility Regulations 2016	24 VDC products: EN 61131-2 220 VAC products: EN 61131-2 EN 61000-3-2 EN 61000-3-3
	RoHS Regulations	Directive (RoHS) Regulations 2012	EN IEC 63000

More Documents

Document Name	Document Coding	Description
Medium-sized PLC Programming Software User Guide	PS00003145	Introduces the basic functions, quick start, network configuration, programming basics, and more of the PLC software.
Medium-Sized PLC Programming Guide (Motion Control)	19010539	Introduces the composition of PLC motion control system, motion control program mechanism, detailed explanation of MC instructions, simulation and debugging related operations.
Medium-Sized PLC Instruction Guide	19011700	Introduces the basic instructions.
AC800 Series Intelligent Mechanical Programmable Controller User Guide (This guide)	19010617	Introduces the installation and wiring of the product, including mechanical installation, electrical installation, and operation instructions.

Revision History

Revision date	Version	Description
February 2025	B07	Made minor corrections.
April 2024	B06	Modified the voltage specifications in "4.3.1 I/O Communication Interface Specifications" on page 28.
January 2024	B05	<ul style="list-style-type: none"> Modified CPU fault codes in "8.2 Appendix 2 Controller Related Error Codes" on page 62. Modified the EtherCAT fault codes in "8.3 Appendix 3 EtherCAT Related Error Codes" on page 64.
July 2023	B04	Made minor corrections.
June 2023	B03	Deleted information on multi-functional expansion card slot. Made minor corrections.
December 2022	B02	Optimized description of the interfaces
November 2022	B01	Made minor corrections.
October 2020	B00	<ul style="list-style-type: none"> Added optional accessory: CAN expansion card. Added information on AC801 and AC812 models. Update the display screen operation and added "Expansion Card Version Information", "Restoring Backup Program", "UPS Settings", and "Restoring Factory Settings" sections.
November 2018	A00	Initial release.

Access to the Guide

This guide is not delivered with the product. You can obtain the PDF version by the following methods:

- Do keyword search under Service and Support at www.inovance.com.

- Scan the QR code on the product with your smart phone.
- Scan the QR code below to install My Inovance app, where you can search for and download user guides.



Warranty Disclaimer

Inovance provides warranty service within the warranty period (as specified in your order) for any fault or damage that is not caused by improper operation of the user. Maintenance will be charged after the warranty expires.

Within the warranty period, maintenance will be charged for the following damage:

- Damage caused by operations not following the instructions in the user guide
- Damage caused by fire, flood, or unusual voltage
- Damage caused by unintended use of the product
- Damage caused by use beyond the specified scope of application of the product
- Damage or secondary damage caused by force majeure (natural disaster, earthquake, and lightning strike)

The maintenance is charged according to the latest Price List of Inovance. If otherwise agreed upon, the terms and conditions in the agreement shall prevail.

For details, see the Product Warranty Card.

First Use

Read through this user guide carefully before use for the first time. If you have any question concerning product functions or performance, contact Inovance for technical support.

Standard

Certification marks on the product nameplate indicate compliance with the corresponding certifications.

Certification	Certification Mark	Directive		Standard
CE Certification		EMC Directive	2014/30/EU	EN 61800-3
		LVD Directive	2014/35/EU	EN 61800-5-1
		RoHS Directive	2011/65/EU	EN 50581
TUV Certification		-	-	EN 61800-5-1
UL Certification		-	-	UL61800-5-1 C22.2 No.14-13
EAC Certification		-	-	CU-TR
KCC Certification		-	-	-
3C Certification		-	-	-

- The integrator who integrates this drive into other products and attaches CE mark to the final assembly has the responsibility of ensuring compliance with CE standards and the European Norm.
- For more information on product certifications, contact Inovance agent.

System Startup Process




Table of Contents

Preface.....	1
First Use	1
Fundamental Safety Instructions.....	6
1 Product Information	12
1.1 Overview	12
1.2 Nameplate and Model Number	12
1.3 Components and Functions	13
1.3.1 Appearance	13
1.3.2 LED Status Indicators.....	15
1.3.3 Power Button	15
1.3.4 Display and Buttons	16
1.3.5 Interfaces.....	16
1.3.6 Spare Parts and Options	18
2 Specifications	19
2.1 General Specifications	19
2.2 Environmental Specifications	20
3 Installation and Fixing.....	21
3.1 Installation Requirements.....	21
3.1.1 Installation Environment.....	21
3.1.2 Installation Space	21
3.1.3 Installation Precautions	22
3.2 Installation Instructions	22
3.2.1 Installation Dimensions	22
3.2.2 Installation Method.....	22
3.3 Installation and Removal of the Fan.....	23
3.4 Installation and Removal of the Battery.....	23
4 Wiring.....	25
4.1 Routing Recommendations	25
4.1.1 Grounding Requirements.....	25
4.1.2 Routing Requirements	26
4.1.3 Installing the Filter	26
4.2 Wiring of Power Input Terminals.....	27
4.3 Wiring of I/O Communication Port.....	28

4.3.1 I/O Communication Interface Specifications	28
4.3.2 Wiring of UPS and Status I/Os	30
4.3.3 RS485 Bus Wiring Instructions.....	31
4.3.4 RS232 Bus Wiring Instructions.....	33
4.4 Wiring of Network Ports	33
4.4.1 Network Port Specifications.....	33
4.4.2 Ethernet Wiring Instructions.....	34
4.4.3 EtherCAT Wiring Instructions	35
4.4.4 Wiring Requirements of Communication Cables.....	36
4.5 Display Interface.....	37
4.6 USB Interface	38
4.7 Cable Selection and Preparation	39
4.7.1 Cable Selection.....	39
4.7.2 Cable Preparation Requirements.....	39
5 Operation Instructions	41
5.1 Power-On	41
5.1.1 Safety Precautions	41
5.1.2 PLC Startup	41
5.1.3 Operations when PLC becomes Operable	41
5.2 Power-Off	42
5.2.1 Safety Precautions	42
5.2.2 Operations at Power-Off.....	43
5.2.3 Operations at Instantaneous Power-off	43
5.2.4 Processing after Power-off Detection.....	44
5.3 Display	45
5.3.1 Menus	45
5.3.2 Main Page	46
5.3.3 Main Menu	46
5.3.4 Page Switchover	54
5.4 System Upgrade.....	54
6 Programming and Debugging	55
7 Maintenance.....	56
7.1 Periodical Maintenance and Inspection.....	56
7.2 Maintenance of the Battery.....	57
7.3 Maintenance of the Fan.....	58

8 Appendix	60
8.1 Appendix 1 Process Codes and Error Codes During BIOS Startup	60
8.2 Appendix 2 Controller Related Error Codes	62
8.3 Appendix 3 EtherCAT Related Error Codes	64

Fundamental Safety Instructions

Safety Precautions

- This chapter provides essential safety instructions for proper use of the equipment. Before operating the equipment, read through the guide and comprehend all the safety instructions. Failure to comply with the safety instructions may result in death, severe personal injuries, or equipment damage.
- "CAUTION", "WARNING", and "DANGER" items in the guide only indicate some of the precautions that need to be followed; they just supplement the safety precautions.
- Use this equipment according to the designated environment requirements. Damage caused by improper use is not covered by warranty.
- Inovance shall take no responsibility for any personal injuries or property damage caused by improper use.

Safety Levels and Definitions



Indicates that failure to comply with the notice will result in death or severe personal injuries.



Indicates that failure to comply with the notice may result in death or severe personal injuries.



Indicates that failure to comply with the notice may result in minor or moderate personal injuries or equipment damage.

General Safety Instructions

- Drawings in the guide are sometimes shown without covers or protective guards. Remember to install the covers or protective guards as specified first, and then perform operations in accordance with the instructions.
- The drawings in the guide are shown for illustration only and may be different from the product you purchased.

Unpacking	
	<ul style="list-style-type: none"> • Do not install the equipment if you find damages, rust, or signs of use on the equipment or accessories upon unpacking. • Do not install the equipment if you find water seepage or missing or damaged components upon unpacking. • Do not install the equipment if you find the packing list does not conform to the equipment you received.

<p> CAUTION</p> <ul style="list-style-type: none">• Check whether the packing is intact and whether there is damage, water seepage, dampness, and deformation before unpacking.• Unpack the package by following the unpacking sequence. Do not strike the package violently.• Check whether there is damage, rust, or injuries on the surface of the equipment and equipment accessories before unpacking.• Check whether the package contents are consistent with the packing list before unpacking.
Storage and Transportation
<p> WARNING</p> <ul style="list-style-type: none">• Large-scale or heavy equipment must be transported by qualified professionals using specialized hoisting equipment. Failure to comply may result in personal injuries or equipment damage.• Before hoisting the equipment, ensure the equipment components such as the front cover and terminal blocks are secured firmly with screws. Loosely-connected components may fall off and result in personal injuries or equipment damage.• Never stand or stay below the equipment when the equipment is being hoisted by the hoisting equipment.• When hoisting the equipment with a steel rope, ensure the equipment is hoisted at a constant speed without suffering from vibration or shock. Do not turn the equipment over or let the equipment stay hanging in the air. Failure to comply may result in personal injuries or equipment damage.
<p> CAUTION</p> <ul style="list-style-type: none">• Handle the equipment with care during transportation and mind your steps to prevent personal injuries or equipment damage.• When carrying the equipment with bare hands, hold the equipment casing firmly with care to prevent parts from falling. Failure to comply may result in personal injuries.• Store and transport the equipment based on the storage and transportation requirements. Failure to comply will result in equipment damage.• Avoid storing or transporting the equipment in environments with water splash, rain, direct sunlight, strong electric field, strong magnetic field, and strong vibration.• Avoid storing the equipment for more than three months. Long-term storage requires stricter protection and necessary inspections.• Pack the equipment strictly before transportation. Use a sealed box for long-distance transportation.• Never transport the equipment with other equipment or materials that may harm or have negative impacts on this equipment.
Installation
<p> DANGER</p> <ul style="list-style-type: none">• The equipment must be operated only by professionals with electrical knowledge. Non-professionals are not allowed.



- Read through the guide and safety instructions before installation.
- Do not install this equipment in places with strong electric or magnetic fields.
- Before installation, check that the mechanical strength of the installation site can bear the weight of the equipment. Failure to comply will result in mechanical hazards.
- Do not wear loose clothes or accessories during installation. Failure to comply may result in an electric shock.
- When installing the equipment in a closed environment (such as a cabinet or casing), use a cooling device (such as a fan or air conditioner) to cool the environment down to the required temperature. Failure to comply may result in equipment over-temperature or a fire.
- Do not retrofit the equipment.
- Do not fiddle with the bolts used to fix equipment components or the bolts marked in red.
- When the equipment is installed in a cabinet or final assembly, a fireproof enclosure providing both electrical and mechanical protections must be provided. The IP rating must meet IEC standards and local laws and regulations.
- Before installing devices with strong electromagnetic interference, such as a transformer, install a shielding device for the equipment to prevent malfunction.
- Install the equipment onto an incombustible object such as a metal. Keep the equipment away from combustible objects. Failure to comply will result in a fire.



- Cover the top of the equipment with a piece of cloth or paper during installation. This is to prevent unwanted objects such as metal chippings, oil, and water from falling into the equipment and causing faults. After installation, remove the cloth or paper on the top of the equipment to prevent over-temperature caused by poor ventilation due to blocked ventilation holes.
- Resonance may occur when the equipment operating at a constant speed executes variable speed operations. In this case, install the vibration-proof rubber under the motor frame or use the vibration suppression function to reduce resonance.

Wiring



- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Before wiring, cut off all the power supplies of the equipment, and wait for at least the time designated on the equipment warning label before further operations because residual voltage still exists after power-off. After waiting for the designated time, measure the DC voltage in the main circuit to ensure the DC voltage is within the safe voltage range. Failure to comply will result in an electric shock.
- Do not perform wiring, remove the equipment cover, or touch the circuit board with power ON. Failure to comply will result in an electric shock.
- Check that the equipment is grounded properly. Failure to comply will result in an electric shock.

 WARNING
<ul style="list-style-type: none">• Do not connect the input power supply to the output end of the equipment. Failure to comply will result in equipment damage or even a fire.• When connecting a drive to the motor, check that the phase sequences of the drive and motor terminals are consistent to prevent reverse motor rotation.• Cables used for wiring must meet cross sectional area and shielding requirements. The shield of the cable must be reliably grounded at one end.• Fix the terminal screws with the tightening torque specified in the user guide. Improper tightening torque may overheat or damage the connecting part, resulting in a fire.• After wiring is done, check that all cables are connected properly and no screws, washers or exposed cables are left inside the equipment. Failure to comply may result in an electric shock or equipment damage.
 CAUTION
<ul style="list-style-type: none">• During wiring, follow the proper electrostatic discharge (ESD) procedure, and wear an antistatic wrist strap. Failure to comply will damage the equipment or the internal circuits of the equipment.• Use shielded twisted pairs for the control circuit. Connect the shield to the grounding terminal of the equipment for grounding purpose. Failure to comply will result in equipment malfunction.
Power-on
 DANGER
<ul style="list-style-type: none">• Before power-on, check that the equipment is installed properly with reliable wiring and the motor can be restarted.• Check that the power supply meets equipment requirements before power-on to prevent equipment damage or a fire.• After power-on, do not open the cabinet door or protective cover of the equipment, touch any terminal, or disassemble any unit or component of the equipment. Failure to comply will result in an electric shock.
 WARNING
<ul style="list-style-type: none">• Perform a trial run after wiring and parameter setting to ensure the equipment operates safely. Failure to comply may result in personal injuries or equipment damage.• Before power-on, check that the rated voltage of the equipment is consistent with that of the power supply. Failure to comply may result in a fire.• Before power-on, check that no one is near the equipment, motor, or machine. Failure to comply may result in death or personal injuries.
Operation
 DANGER
<ul style="list-style-type: none">• The equipment must be operated only by professionals. Failure to comply will result in death or personal injuries.• Do not touch any connecting terminals or disassemble any unit or component of the equipment during operation. Failure to comply will result in an electric shock.
 WARNING
<ul style="list-style-type: none">• Do not touch the equipment casing, fan, or resistor with bare hands to feel the temperature. Failure to comply may result in personal injuries.• Prevent metal or other objects from falling into the equipment during operation. Failure to comply may result in a fire or equipment damage.
Maintenance

<p> DANGER</p> <ul style="list-style-type: none"> • Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals. • Do not maintain the equipment with power ON. Failure to comply will result in an electric shock. • Before maintenance, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label. • In case of a permanent magnet motor, do not touch the motor terminals immediately after power-off because the motor terminals will generate induced voltage during rotation even after the equipment power supply is off. Failure to comply will result in an electric shock.
<p> WARNING</p> <ul style="list-style-type: none"> • Perform routine and periodic inspection and maintenance on the equipment according to maintenance requirements and keep a maintenance record.
<p>Repair</p>
<p> DANGER</p> <ul style="list-style-type: none"> • Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals. • Do not repair the equipment with power ON. Failure to comply will result in an electric shock. • Before inspection and repair, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.
<p> WARNING</p> <ul style="list-style-type: none"> • Require repair services according to the product warranty agreement. • When the fuse is blown or the circuit breaker or earth leakage current breaker (ELCB) trips, wait for at least the time designated on the equipment warning label before power-on or further operations. Failure to comply may result in death, personal injury or equipment damage. • When the equipment is faulty or damaged, the troubleshooting and repair work must be performed by professionals that follow the repair instructions, with repair records kept properly. • Replace quick-wear parts of the equipment according to the replacement instructions. • Do not use damaged equipment. Failure to comply may result in death, personal injuries, or severe equipment damage. • After the equipment is replaced, check the wiring and set parameters again.
<p>Disposal</p>
<p> WARNING</p> <ul style="list-style-type: none"> • Dispose of retired equipment in accordance with local regulations and standards. Failure to comply may result in property damage, personal injuries, or even death. • Recycle retired equipment by observing industry waste disposal standards to avoid environmental pollution.

Safety label

For safe equipment operation and maintenance, comply with the safety labels on the equipment. Do not damage or remove the safety labels. See the following table for descriptions of the safety labels.

Safety Label	Description
	<ul style="list-style-type: none">• Read through the safety instructions before operating the equipment. Failure to comply may result in death, personal injuries, or equipment damage.• Do not touch the terminals or remove the cover with power ON or within 10 min after power-off. Failure to comply will result in an electric shock.

1 Product Information

1.1 Overview

The AC800 series intelligent mechanical programmable controller adopts a book-style form factor with an all-metal body, offering abundant network interfaces capable of meeting various project expansion requirements, and delivers robust motion control performance. The controller supports multiple interfaces, including up to two Gigabit Ethernet ports, two EtherCAT interfaces, two USB2.0 interfaces, two USB3.0 interfaces, one RS485 interface, and one RS232 interface.

This product series features a wide operating temperature range (-5°C to +55°C) and excellent EMC performance. The controller is equipped with an Intel Celeron or Core i CPU with excellent computing capabilities, a 4 GB or above DDR4 memory and a large SSD, which make it a perfect match for high-load computing applications.


1.2 Nameplate and Model Number

Description of model number

 A C 8 1 0 - 0 1 2 2 - U 0 R 0
 ① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨


① Product name A: Controller	④ Sub-series number (2nd digit) 1: Core i series processor	⑦ Software configuration W: Windows system L: Linux system U: Ubuntu system V: Vxworks system
② Product structure type C: Booksize	⑤ Model 0: AC810	⑧ Software configuration 0: system version
③ Series number (1st digit) 8: 800 series	⑥ Hardware Configuration First two digits: CPU configuration (00 to 99), 00: i3, 01: i5; 02: Celeron; 03: i7 3rd digit: Standard memory: 2 ⁿ × 1 GB (1 GB to 16 GB Max. 512 GB) (where n corresponds to the 3rd digit) 4th digit: Standard SSD: 2 ⁿ × 32 GB (32 GB to 256 GB Max. 16 TB) (where n corresponds to the 4th digit)	⑨ Software configuration R0: Software specification + version

Description of nameplate



1.3 Components and Functions

1.3.1 Appearance



The AC800 series includes the following controllers and accessories:

Product Type	Product description	Model	Product Code
Booksize controller	Intel Core i7; 4 GB memory; 128 GB hard drive; 2x USB2.0 interfaces; 2x USB3.0 interfaces; 4x network ports; DVI-D; with display; internal Mini-PCIE expansion slot	AC812-0322-U0R0	01440143
Booksize controller	Intel Core i5; 4 GB memory; 128 GB hard drive; 2x USB2.0 interfaces; 2x USB3.0 interfaces; 4x network ports; DVI-D; with display; internal Mini-PCIE expansion slot	AC810-0122-U0R0	01440038


Product Type	Product description	Model	Product Code
Booksized controller	Celeron; 4 GB memory; 128 GB hard drive; 2x USB2.0 interfaces; 2x USB3.0 interfaces; 4x network ports; DVI-D; with display; internal Mini-PCIE expansion slot	AC802-0222-U0R0	01440101
Booksized controller	Celeron; 4 GB memory; 64 GB hard drive; 2x USB2.0 interfaces; 2x USB3.0 interfaces; 4x network ports; DVI-D; with display; internal Mini-PCIE expansion slot	AC801-0221-U0R0	01440103

The external interfaces of the controller are shown in the following figure:

Table 1-1 Controller interfaces

-	No.	Interface name	Description
	①	Rear earhook	Standard
	②	Status indicator	For the specific definition of the indicators, see “1.3.2 LED Status Indicators” on page 15
	③	Display and Buttons	For specific functions and operations, see section 5.
	④	Reset button	Pinhole reset button
	⑤	I/O communication interface	3x DIs/2x DOs, RS485/RS232, for details on the pins, see section “4.3.3 RS485 Bus Wiring Instructions” on page 31
	⑥	Power supply interface	24 V power supply input
	⑦	Fan slot locker (only available in AC810 and AC812 series)	Remove this to replace the fan and RTC battery
	⑧	Grounding terminal	Controller grounding
	⑨	DVI-D interface	Standard DVI-D Display interface
	⑩/⑪	LAN port	4x LAN ports: 2x Ethernet and 2x EtherCAT (1x EtherCAT in AC801 series)
	⑫/⑬	USB interface	2x USB 2.0 ports and 2x USB 3.0 ports
	⑭	Power button	Controller startup control

1.3.2 LED Status Indicators



The indicators are described as follows:

No.	LED	Name	Function	Status	Description
1	PWR	Power indicator	Controller power status	Green	OFF: Abnormal ON: Normal
2	RUN	RUN indicator	Running status	Green	OFF: User program is not running. Blinking: The device is being identified. ON: User program is running.
3	HDD	Hard drive indicator	Hard drive status	Green	OFF: HDD not detected. Blinking: HDD is working normally.
4	ERR	Error indicator	Operation error	Red	OFF: Normal Blinking: Low battery ON: 1. Overtemperature 2. User program error 3. System failure

1.3.3 Power Button

The power button is located under the front panel of the controller. See the following for the details:

No.	Operation	Result
1	Power-on	The controller is turned on.
2	Pressing the button after power-on	No operation
3	Long pressing the button after power-on	The controller is shut down.
4	Pressing the button upon power on after the controller is shut down.	The controller is turned on.

1.3.4 Display and Buttons




Figure 1-1 Display

The controller display is used to display basic information and perform simple commissioning. The display parameter specifications are as follows:

Item	Description
Outline dimensions	31.46 x 36.68
Visible area	16.3 x 28.78
Display type	FSTN negative display
Resolution	128 x 64

Functions of the buttons are described in the following table:

Item	Description
Button 1	Back
Button 2	Page up
Button 3	Page down
Button 4	Enter


The display shows the information on the following. For detailed operation instructions, see “[Programming and Debugging](#)” on page 55.







1. system operation
2. controller status
3. fault and commissioning
4. basic controller information: basic hardware information, software version, and IP address
5. upgrade and download progress

1.3.5 Interfaces



The following table summarizes all the interfaces of the controller:

No.	Interface name	Function	Interface type	Terminal
1	Input power supply	24 VDC (-20% to +20%)	3-pin pluggable 5.08 Eurostyle terminal, spring crimping, with fixing screws, black	
2	I/O communication terminal	3DI, 2DO RS485 interface RS232 interface	2 * 6-pin pluggable 3.5 mm Eurostyle terminals, spring crimping, with fixing screws, black	

No.	Interface name	Function	Interface type		Terminal																									
3	Ethernet port	4 LAN ports: LAN A, LAN B, LAN C and LAN D (top to bottom). The Ethernet interface utilizes an Intel Gigabit Ethernet controller, fully compliant with 802.1Qav, IEEE1588/802.1AS, 802.3az and Intel® AMT functional requirements (Intel AMT supports Core i processors with specific SKU). Four standard RJ-45 Ethernet interfaces. The LED indicators are described as follows:																												
4	EtherCAT port		<table border="1"> <thead> <tr> <th>Indicator</th> <th>Function</th> <th>Color</th> <th>Status</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td rowspan="3">A</td> <td rowspan="3">A: Link/Act</td> <td rowspan="3">Yellow</td> <td></td> <td>OFF: Not connected</td> </tr> <tr> <td></td> <td>Flashing: Sending/receiving data</td> </tr> <tr> <td></td> <td>ON: Connected</td> </tr> <tr> <td rowspan="4">B</td> <td rowspan="4">B: Speed</td> <td rowspan="4">Green/orange</td> <td></td> <td>OFF: 1. Connection at 10 Mbps 2. No connection</td> </tr> <tr> <td></td> <td>ON: Connection at 100 Mbps</td> </tr> <tr> <td></td> <td>ON: Connection at 1,000 Mbps</td> </tr> <tr> <td></td> <td>ON: Connection at 1,000 Mbps</td> </tr> </tbody> </table>	Indicator	Function	Color	Status	Meaning	A	A: Link/Act	Yellow		OFF: Not connected		Flashing: Sending/receiving data		ON: Connected	B	B: Speed	Green/orange		OFF: 1. Connection at 10 Mbps 2. No connection		ON: Connection at 100 Mbps		ON: Connection at 1,000 Mbps		ON: Connection at 1,000 Mbps		
			Indicator	Function	Color	Status	Meaning																							
A	A: Link/Act	Yellow		OFF: Not connected																										
				Flashing: Sending/receiving data																										
				ON: Connected																										
B	B: Speed	Green/orange		OFF: 1. Connection at 10 Mbps 2. No connection																										
				ON: Connection at 100 Mbps																										
				ON: Connection at 1,000 Mbps																										
				ON: Connection at 1,000 Mbps																										
Description:		<table border="1"> <thead> <tr> <th>Port</th> <th>Description</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>LAN A</td> <td>Ethernet 1</td> <td>1. System program commissioning 2. User program download and commissioning 3. Modbus TCP protocol 4. Socket (TCP, UDP)</td> </tr> <tr> <td>LAN B</td> <td>Ethernet 2</td> <td>1. Modbus TCP protocol 2. Socket (TCP, UDP)</td> </tr> <tr> <td>LAN C</td> <td>EtherCAT1</td> <td>1. EtherCAT protocol 2. Auto scanning 3. Independent axis/IO</td> </tr> <tr> <td>LAN D</td> <td>EtherCAT2</td> <td>1. EtherCAT protocol 2. Auto scanning 3. Independent axis/IO</td> </tr> </tbody> </table>				Port	Description	Function	LAN A	Ethernet 1	1. System program commissioning 2. User program download and commissioning 3. Modbus TCP protocol 4. Socket (TCP, UDP)	LAN B	Ethernet 2	1. Modbus TCP protocol 2. Socket (TCP, UDP)	LAN C	EtherCAT1	1. EtherCAT protocol 2. Auto scanning 3. Independent axis/IO	LAN D	EtherCAT2	1. EtherCAT protocol 2. Auto scanning 3. Independent axis/IO										
Port	Description	Function																												
LAN A	Ethernet 1	1. System program commissioning 2. User program download and commissioning 3. Modbus TCP protocol 4. Socket (TCP, UDP)																												
LAN B	Ethernet 2	1. Modbus TCP protocol 2. Socket (TCP, UDP)																												
LAN C	EtherCAT1	1. EtherCAT protocol 2. Auto scanning 3. Independent axis/IO																												
LAN D	EtherCAT2	1. EtherCAT protocol 2. Auto scanning 3. Independent axis/IO																												

No.	Interface name	Function	Interface type	Terminal																																																					
5	DVI socket	Standard DVI-D communication	Standard DVI-I socket, white plastic, with shielded housing																																																						
6	USB2.0	The controller provides 4 USB interfaces, all of which support plug-and-play and hot plugging, and can connect up to 127 external devices. Two USB 2.0 and two USB 3.0. The interfaces conform to the USB EHCI, Rev. 2.0 standard. Pin definition is as below:																																																							
7	USB3.0	<table border="1"> <thead> <tr> <th colspan="4">USB2.0 Pin Definition</th> </tr> <tr> <th></th> <th>Pin</th> <th>Signal name</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td rowspan="4"></td> <td>1</td> <td>VCC</td> <td>Power supply</td> </tr> <tr> <td>2</td> <td>DATA-</td> <td rowspan="2">USB2.0 differential data signal</td> </tr> <tr> <td>3</td> <td>DATA+</td> </tr> <tr> <td>4</td> <td>GND</td> <td>Power supply GND</td> </tr> <tr> <th colspan="4">USB3.0 Pin Definition</th> </tr> <tr> <th></th> <th>Pin</th> <th>Signal name</th> <th>Function</th> </tr> <tr> <td rowspan="9"></td> <td>1</td> <td>VCC</td> <td>Power supply</td> </tr> <tr> <td>2</td> <td>DATA-</td> <td rowspan="2">USB2.0 differential data signal</td> </tr> <tr> <td>3</td> <td>DATA+</td> </tr> <tr> <td>4</td> <td>GND</td> <td>Power supply GND</td> </tr> <tr> <td>5</td> <td>SSRX-</td> <td rowspan="2">High speed reception differential data signal</td> </tr> <tr> <td>6</td> <td>SSRX+</td> </tr> <tr> <td>7</td> <td>GND</td> <td>Signal ground</td> </tr> <tr> <td>8</td> <td>SSTX-</td> <td rowspan="2">High speed transmission differential data signal</td> </tr> <tr> <td>9</td> <td>SSTX+</td> </tr> </tbody> </table>		USB2.0 Pin Definition					Pin	Signal name	Function		1	VCC	Power supply	2	DATA-	USB2.0 differential data signal	3	DATA+	4	GND	Power supply GND	USB3.0 Pin Definition					Pin	Signal name	Function		1	VCC	Power supply	2	DATA-	USB2.0 differential data signal	3	DATA+	4	GND	Power supply GND	5	SSRX-	High speed reception differential data signal	6	SSRX+	7	GND	Signal ground	8	SSTX-	High speed transmission differential data signal	9	SSTX+	
USB2.0 Pin Definition																																																									
	Pin	Signal name	Function																																																						
	1	VCC	Power supply																																																						
	2	DATA-	USB2.0 differential data signal																																																						
	3	DATA+																																																							
	4	GND	Power supply GND																																																						
USB3.0 Pin Definition																																																									
	Pin	Signal name	Function																																																						
	1	VCC	Power supply																																																						
	2	DATA-	USB2.0 differential data signal																																																						
	3	DATA+																																																							
	4	GND	Power supply GND																																																						
	5	SSRX-	High speed reception differential data signal																																																						
	6	SSRX+																																																							
	7	GND	Signal ground																																																						
	8	SSTX-	High speed transmission differential data signal																																																						
	9	SSTX+																																																							

1.3.6 Spare Parts and Options

No.	Name	Diagram	Description	Ordering code
1	RTC button battery CR2032		3 V, 230 mAh	09050002
2	fan components		70,000 Hours at 40°C, 65% RH	98050167
3	UPS	-	An external UPS power supply is required for retentive at power failure.	72030025

2 Specifications

2.1 General Specifications

The AC800 series includes several controllers, whose basic specifications are shown in the following table:

Item	AC801-0221-U0R0	AC802-0222-U0R0	AC810-0122-U0R0	AC812-0322-U0R0
Power supply	24 VDC (-20% to +20%)			
CPU Model	Celeron	Celeron	Core i5	Core i7
Memory	4 GB	4 GB	4 GB	4 GB
Memory type	DDR4 SO-DIMM	DDR4 SO-DIMM	DDR4 SO-DIMM	DDR4 SO-DIMM
Hard disk capacity	64 GB	128 GB	128 GB	128 GB
Hard drive type	M.2(M key) SSD	M.2(M key) SSD	M.2(M key) SSD	M.2(M key) SSD
SPI FLASH	64Mbit	64Mbit	64Mbit	64Mbit
Programming mode	IEC 61131-3 programming language (LD, ST, SFC, CFC)	IEC 61131-3 programming language (LD, ST, SFC, CFC)	IEC 61131-3 programming language (LD, ST, SFC, CFC)	IEC 61131-3 programming language (LD, ST, SFC, CFC)
Program execution mode	Compiling execution	Compiling execution	Compiling execution	Compiling execution
User program storage space	128 MB	128 MB	128 MB	128 MB
User data storage space	128 MB	128 MB	128 MB	128 MB
EtherCAT communication	1 (each supports up to 128 slaves)	2 (each supports up to 128 slaves)	2 (each supports up to 128 slaves)	2 (each supports up to 128 slaves)
Modbus TCP communication	2 (each supports up to 63 slaves)			
Modbus (serial port) communication	2 (each supports up to 31 slaves)			
Retentive space upon power failure	5 MB, requires external UPS			
Dimensions (W x H x D)	60 mm x 225 mm x 164 mm	60 mm x 225 mm x 164 mm	60 mm x 225 mm x 164 mm	60 mm x 225 mm x 164 mm
Weight	Approx. 2.5 kg	Approx. 2.5 kg	Approx. 2.5 kg	Approx. 2.5 kg
Cooling method	Natural cooling	Natural cooling	Fan cooling	Fan cooling
Battery life	5 years at 25°C, non-energized			
EMC specifications	EN61131-2 Zone B/EN61000-6-2/EN61000-6-4			

2.2 Environmental Specifications

The environmental specifications of the controller are shown in the following table:

Item	Type	Operating specification	Transportation	Storage	
Environmental parameters (IEC60721-3)	Class	IE33	IE22	IE12	
	Temperature	-5°C to +55°C	-40°C to +70°C	-25°C to +70°C	
	Humidity	10% RH to 95% RH, without condensation			
	Vibration	Frequency	5 Hz to 200 Hz	2M2	1M2
		Displacement	3.5 mm (direct installation) (< 8.4 Hz)		
		Acceleration	1 g (direct installation) (> 8.4 Hz)		
		Direction	3-axial directions		
	Shock (collision)	15 g, 11 ms, half sine wave, 3-axial directions			
Altitude/Air pressure	0 m to 2,000 m	0 m to 3,000 m (\leq 70 kPa)			

3 Installation and Fixing

3.1 Installation Requirements

3.1.1 Installation Environment


When installing the controller on the guide rail, take the operability, maintainability, and robustness into account. Do not install the module in a location which is subject to

- An ambient temperature exceeding the range of -5°C to +55°C
- An ambient humidity exceeding the range of 5% to 95% RH
- Drastic temperature changes and condensation
- Corrosive and flammable gas
- Conductive powders (such as dust and iron powder), oil mist, salt, and organic solvents
- Direct sunlight
- Strong electric and magnetic fields
- Vibration or shocks

3.1.2 Installation Space

To facilitate ventilation and module replacement, keep enough space between the module and its surroundings.

Installation diagram:



Rear earhook bracket installation

Figure 3-1 Installation space for booksize controller

The clearances are shown in the following table:

Direction	Minimum requirement on cabinet dimensions (mm)
X	50
Y	100
Z	50

3.1.3 Installation Precautions

- Before installation, ensure that the controller is powered off.
- To avoid damage to the controller, do not drop or shock the controller's housing, terminal block, or connector.
- Do not disassemble the controller; otherwise the controller may be damaged.
- To avoid damage to the terminal and controller, do not overtighten the fasteners.
-  The left panel of the controller is an aluminum plate for heat dissipation. Exercise caution to avoid burns.

3.2 Installation Instructions

3.2.1 Installation Dimensions

The installation dimensions of the controller are shown in the following figure:





Figure 3-2 Installation dimensions (rear earhook)


3.2.2 Installation Method

- 1) Rear earhook




3.3 Installation and Removal of the Fan

Fan (mm)



Removal

The bottom fan is removed as follows:



1. Unscrew the screws on the fan with your hand.
2. Pull out the fan assembly in the direction shown in the figure. Be careful not to damage the bottom wedge.
3. Remove the fan assembly.

Installation

Install the fan in reverse order.

3.4 Installation and Removal of the Battery

Prerequisite

The battery can only be installed or removed after the fan is removed. Remove the fan as instructed in section [“3.3 Installation and Removal of the Fan” on page 23](#) first.


Note

- When removing the battery, be careful not to touch the surrounding parts to avoid damage. Live working is not allowed.


- When installing the battery, see the label at the bottom of the battery to identify the battery's positive and negative poles.
- After replacing the battery, you need to manually start the controller.
- After replacing the battery, power on the controller and check if the controller reports a battery error. If such an error is reported, check whether the battery is installed correctly.
- If the controller is powered on without reporting any error, recalibrate the system clock.
- Do not replace the battery in environments with potential explosion hazards such as gas, vapor, dust, or fibers.
- Dispose of the removed battery properly to avoid environmental pollution and physical injury.

Operating procedure

1. Loosen the screws on the bottom of the controller and open the fan cover. You can see the battery as shown below.



2. Clamp the battery with flat-nose pliers and remove it along the parallel direction of the battery slot.



3. Use your fingers to push the new battery into the battery slot.


4 Wiring

4.1 Routing Recommendations

4.1.1 Grounding Requirements

A grounding point (⏏) is set on the power terminal of the controller and the rear earhook each. Choose one of the grounding points as needed. Use a grounding wire that is as thick and short (less than 30 cm) as possible to ground the controller. The grounding point on the back earhook is recommended.

Use a wing nut for grounding, with a tightening torque of 0.55 N.m to 0.8 N.m, as shown below:



1-Wing nut;

2-Grounding cable;

3-Grounding screw

Figure 4-1 Grounding the controller

Grounding of shielded cables

Communication cables must be shielded cables. Ground the shielded cable as close to the controller as possible so that the cable is not interfered with by electromagnetic induction. The exposed shielded cable must touch the grounding point as much as possible to ensure good contact.

Do not solder a PVC wire to the shielded cable for grounding because this will increase the high frequency impedance and attenuate the shielding effect. Attention should be paid to avoid this whenever possible. The shielded cables of the communication signal cable must be grounded at both ends.




Figure 4-2 Grounding the shielded cable

4.1.2 Routing Requirements

Low-voltage cables (< 1 KV) are generally divided into four types. Only cables of the same type can be bundled together. Cables of different types must be separated without cross-connection or overlap. If cross-connection cannot be avoided, make them cross-connected at 90 degrees.

No.	Category	Application
1	I	Ethernet port and EtherCAT port
2	II	Low-speed digital communication signals (RS232 and RS485) and DI/DO signals
3	III	Low-voltage AC power distribution cables or DC power supply cables (such as 24 VDC power supply cables with switched-mode power supply)
4	IV	Input and output cables, welding machine cables, and power converter power cables

Keep a proper distance between different types of cables. For cables shorter than 30 m, the minimum distance allowed is shown in the figure below.




Figure 4-3 Required distances between different types of cables

Note

- If two cables run parallel for an extended length, increase the distances accordingly.
- You can also install spliced shielding plates between different types of cables. To reduce cross interference, route all cables as closely as possible to the grounded structural components of the cabinet, such as the cabinet's mounting plate or rack components.

4.1.3 Installing the Filter

If the controller is subject to a strong interference source (such as an AC drive), it is recommended that you add a noise filter to suppress the interference.

Install the filter as close as possible to the power supply of the controller. Fix the filter to the conductive backplane through screws. Protect the area around the screws with paint and ensure reliable grounding. The outgoing and incoming cables of the filter should be routed separately to avoid noise coupling on the cables.




Figure 4-4 Installing the filter

4.2 Wiring of Power Input Terminals

The power input terminal is a 3-pin screw-fixed pluggable terminal with a pitch of 5.08 mm. To facilitate wiring, replacement and maintenance, use a spring clamp crimping terminal. The following illustration shows how the power supply cable connector is inserted into the power input terminal:





Figure 4-5 Wiring of power input terminals

1. Definition of the power terminals

Terminal	No.	Name	Type	Function
	1	+24 V	Input	DC input positive
	2	0 V	Input	DC input negative
	3		Grounding	Enclosure protective GND

2. Specifications of input power supply

No.	Item	Specification
1	Input voltage	24 VDC (-20% to +20%)
2	Input current	3 A
3	Fool-proof design for connection	Supported
4	Short-circuit protection	Supported

The power input must be equipped with a fuse.

3. Power supply cable preparation

The power supply input cable uses a pin terminal. For preparation instructions, see section [“4.7.2 Cable Preparation Requirements” on page 39](#).

4.3 Wiring of I/O Communication Port

4.3.1 I/O Communication Interface Specifications

1 Introduction

The I/O communication interface adopts a 12-pin (dual-row 6-pin) terminal with a 3.5mm pitch, which includes UPS auxiliary signals, RS-232 signals, RS-485 signals, power-on signals, PLC program run/stop control signals, and power status signals. The wiring terminal adopts screw-fixed pluggable terminals, utilizing spring-type and crimping connection methods for convenient on-site installation and wiring, replacement and maintenance.

The following configure shows the connection of the IO/communication terminal plug to the IO/communication interface.





Figure 4-6 User terminal wiring diagram

2 Definition of I/O communication interface

Description	Function	Signal	No.	I/O communication interface	No.	Signal	Function	Description
Starts the PLC through a 500 ms high level width pulse	On signal (works with UPS or remote start)		1		2	P_STATUS	Power-on indicator signal	Active after the controller is powered on
Enables power failure retention during ON-OFF switchover	Power failure detection signal	P_OK	3		4	P_STATUS	Operation status signal	Active after the controller is powered on
OFF during RUN; ON during STOP	RUN/STOP	RUN	5		6	0 V	DO reference GND	-
-	Input common terminal	0 V	7		8	GND	Communication reference ground	-
COM1	RS485+	485+	9		10	232R	RS232 reception	COM0
	RS485-	485-	11		12	232T	RS232 transmission	

Note

The status control signals in the above table are dedicated I/Os and cannot be used otherwise.

3 Specifications of status control signals

The specifications of the status control signals are described in the following table:

Item	Input Signal (pin 1/3/5)	Output Signal (pin 2/4)
I/O type	DC digital input	Transistor, high-level output
I/O mode	Source	Source
Input/Output voltage class	24 VDC (-20% to +20%)	24 VDC (-20% to +20%)
	OFF voltage: $\leq 5\text{ V}$ ON voltage: $\geq 15\text{ V}$	
ON response time	Less than 10 ms (hardware response time)	Less than 0.5 ms (hardware response time)
OFF response time	Less than 10 ms (hardware response time)	Less than 0.5 ms (hardware response time)
Isolation mode	Optocoupler isolation	Optocoupler isolation
Short circuit-proof output	N/A	Supported

4 RS-485 communication specifications

RS485 communication supports the Modbus RTU protocol and free protocol, with relevant specifications as described in the following table.

No.	Item	Specification
1	Station number	1 to 247
2	Communication rate (bps)	4.8K, 9.6K, 19.2K, 38.4K, 57.6K, 115.2K
3	Data length	8 bits
4	Parity check bit	None/Odd/Even
5	Stop bit	1.2
6	Max. number of stations	32

5 RS-232 communication specifications

The RS232 bus supports the following communication specifications as described in the following table.

No.	Item	Specification
1	Number of slaves	1
2	Communication rate (bps)*	300, 600, 1.2K, 2.4K, 4.8K, 9.6K, 19.2K, 38.4K, 57.6K, 115.2K

Note

When you use an RS232 to RS485 converter, it is recommended that you use an external power supply to power the converter. If the external power supply is unavailable, the baud rate should not exceed 9.6 kbps.

4.3.2 Wiring of UPS and Status I/Os

To enable power failure retention, a GA10–UPS12 UPS is required. The recommended wiring method for UPS and other I/O control signals is shown in the figure below:




Figure 4-7 UPS connection

Note

The power failure detection signal P_OK, common input terminal and remote start signal terminals must be connected according to the preceding figure. For other state signal terminals, connect them as required.

Wiring of P_OK power failure detection signal: See the above figure. When a power failure occurs, the signal turns from ON to OFF, and the PLC saves data and shuts down.

⏻ Wiring of power-on signal: If a power failure occurs, take measures according to the following situations:

- If the power is recovered before the UPS runs out of power, press the power button on the PLC to turn it on. If the PLC is installed inside the cabinet and its power button is inconvenient to operate, it is recommended to connect the 24V power supply to the ⏻ signal via a non-latching button, enabling PLC startup through operating this non-latching button.
- If the power is recovered after the UPS runs out of power, the UPS charging signal will be sent to the PLC, at which point the PLC will automatically start up.

4.3.3 RS485 Bus Wiring Instructions

The RS485 bus connection topology is shown in the figure below. It is recommended to use shielded twisted-pair cables for RS485 bus connection and twisted pairs for RS485+ and RS485- connection. Install a termination resistor with the resistance of 120 Ω at both ends of the bus to prevent signal reflection. Connect the reference grounds of RS485 signals for all nodes together. A maximum of 32 nodes is supported and the distance between the node and the RS485 bus must be less than 3 m.




Figure 4-8 RS485 communication connection

Multi-node connection

In case of a large number of nodes, connect the RS485 bus using the daisy chain mode. If branches need to be connected, keep the cable length between the bus and the node as short as possible, preferably not exceeding 3 m. Star connections are prohibited. Common bus structures are shown in the following figures.




Figure 4-9 Daisy chain connection mode




Figure 4-10 Branch connection structure





Figure 4-11 Star connection structure (wrong)

Terminal wiring

The controller provides three terminals (485+, 485- and GND) for RS485 communication. Ensure that the RS485 bus contains three cables, and the terminals are connected correctly. If you are using shielded cables, the shielding layer must be connected to the GND terminal, rather than any other location (including housings and equipment ground terminals).

Due to cable attenuation, use AWG26 or thicker cables for connection longer than 3 m. Twisted pair cables are always recommended for connecting RS485+ and RS485- terminals.



a. Multicore unshielded cable

b. Shielded twisted pair

Figure 4-12 Terminal wiring diagram

- Recommended cable 1: Use multi-conductor twisted pair cables, with one twisted pair connected to 485+ and 485-, and others twisted together to connect GND.
- Recommended cable 2: Use shielded twisted pair cables, with the twisted pair connected to 485+ and 485-, and the shield layer connected to GND.

Note

Particular attention must be paid to scenarios where shielded cables are used as connection wiring—the shielding layer should only be connected to GND and must not be connected to the site ground.

4.3.4 RS232 Bus Wiring Instructions

When you use an RS232 to RS485 converter, it is recommended that you use an external power supply to power the converter. If the external power supply is unavailable, the baud rate should not exceed 9.6 kbps.

4.4 Wiring of Network Ports

4.4.1 Network Port Specifications

The AC800 series controller provides four gigabit Ethernet ports, which are described as follows:

No.	Port	Function
1	LAN A	Programming port (used for downloading and monitoring), Modbus TCP, EtherNet/IP, OPC UA communication port
2	LAN B	Modbus TCP, EtherNet/IP, OPC UA communication port
3	LAN C	The EtherCAT master network port supports a communication rate of only 100M when used as an EtherCAT network port.
4	LAN D	

Note

The IP addresses of LAN A and LAN B ports must not be within the same subnet.

Gigabit Ethernet specifications

- Supports 2x standard Ethernet interfaces.
- Supported protocols: Modbus TCP, EtherNet/IP, OPC UA.

The Modbus TCP communication specifications are as follows in the table.

Item	Specification
Station number	1 to 247
Communication rate	10M/100M/1000M adaptive
Data length	8 bits
Parity check bit	None/Odd/Even
Stop bit	1, 2
Max. number of stations	64
Special functions	Diagnostic function

The OPC UA communication specifications are as follows in the table.

Item	Specification
Security policy	-
User authentication	Anonymous
Server port	4840
Session timeout (s)	5 to 600,000
Sampling interval (ms)	100, 300, 500, 1,000, 2,500, 5,000
Publish interval (ms)	200 to 20,000,000

Item	Specification
Maximum number of sessions	50
Maximum number of subscriptions per server	200
Maximum number of monitored nodes per server	20,000
Maximum number of subscriptions per session	50
Maximum number of monitored nodes per subscription	10,000
Maximum number of nodes for single-frame read/write	1,000

EtherCAT communication specifications

The LAN C and LAN D interfaces support EtherCAT communication, with specific specifications as described in the following table:

Item	Specification
Communication Protocol	EtherCAT protocol
Supported services	FoE, CoE (PDO, SDO)
Min. synchronization period of the 12-axis cam	500 μ s (typical)
Max. sync jitter	± 40 μ s
Max. axes	256
Synchronization mode	The servo comes with a distributed clock for synchronized inputs and outputs.
Physical layer	100BASE-TX
Baud rate	100 Mbps (100Base-TX)
Duplex mode	Full duplex
Topology	Ring
Transmission medium	Network cable, see cable specifications in the following section
Transmission distance	Less than 100 m between two nodes
Number of slaves	256
EtherCAT frame length	44 bytes to 1,498 bytes
Process Data	Max. 1,486 bytes per Ethernet frame
Synchronous jitter of two slaves	< 1 μ s
Refresh time	About 30 μ s for 1,000 digital inputs and outputs About 100 μ s for 32 servo axes
DLR function	Supported by AC801, not supported by AC802/AC810/AC812
Automatic scanning function	Supported

4.4.2 Ethernet Wiring Instructions

Networking

With the Ethernet port, the controller can be connected point-to-point with devices such as a computer and HMI through an Ethernet cable.




Figure 4-13 Connecting controller to PC

The controller can also be connected to a hub or switch, which is further connected with other network devices, through an Ethernet cable to achieve multi-point connection.




Figure 4-14 Connecting controller to other devices through switch

4.4.3 EtherCAT Wiring Instructions

With the EtherCAT port, the controller can be connected to various servo drives, slave modules or expansion modules that support EtherCAT communication.




Figure 4-15 Connecting controller to other devices through EtherCAT port

4.4.4 Wiring Requirements of Communication Cables

Connection of RJ45 cable

Connection: Insert the cable into the RJ45 port of the communication module until you hear a click sound.




Figure 4-16 Connection of RJ45 cable

Removal: Press the tail of the registered jacket to pull out the connector.

Requirements on Ethernet cable

Use Cat 5e STP and injection cable with iron housing.

Figure 4-17 Requirements on Ethernet cable

Unshielded cable	Shielded cable
	

Cable Preparation




Figure 4-18 Requirement on the EtherCAT cable

Signal pin assignment

Pin	Signal (Ethernet 1,000 Mbps)	Signal Direction	Signal Description
1	TD+	Output	Data transmission+
2	TD-	Output	Data transmission-
3	RD+	Input	Data reception +
4	-(DC+*)	-(bidirectional)	Unused (data C+)
5	-(DC-)	-(bidirectional)	Unused (data C+)
6	RD-	Input	Data reception -
7	-(DD+)	-(bidirectional)	Unused (data D+)
8	-(DD-)	-(bidirectional)	Unused (data D+)

*Note: The definition of pins 4, 5, 7, and 8 under 1,000 Mbps differs from that under 100 Mbps. Pay attention to the information in parentheses.

- **Length requirements:**

When an EtherCAT bus is used, the length of the cable between the devices must not exceed 100 meters. Exceeding this length will attenuate the signal and affect communication.

- **Technical requirements:**

1. 100% continuity test without short circuit, open circuit, misalignment, or poor contact.
2. The cable length is within the allowable tolerance range.

STP is used as EtherCAT bus for network data transmission. Cables with the following specifications are recommended:


Item	Specification
Cable type	Flexible crossover cable, S-FTP, Cat 5e
Standards compliance:	EIA/TIA568A, EN50173, ISO/IEC11801 EIA/TI Abulletin TSB, EIA/TIA SB40-A&TSB36
Cross sectional area	AWG26
Conductor type	Twisted pair
Number of pairs	4

4.5 Display Interface

The controller provides a standard DVI-D display interface with the following specifications (no cable is provided):

Item	Specification
Signal type	DVI-D (digital signal)
Interface type	24+1
Number of channels	Single-channel
Max. resolution	1920 x 1200 @60 Hz

The DVI-D interface is detailed in the following table:

Illustration	Pin	Signal	Pin	Signal
	1	TMDS data 2-	13	TMDS data 3+
	2	TMDS data 2+	14	+5 V DC power supply
	3	TMDS data 2/4 mask	15	GND (+5 V circuit)
	4	TMDS data 4-	16	Hot swapping detection
	5	TMDS data 4+	17	TMDS data 0-
	6	DDC clock	18	TMDS data 0+
	7	DDC data	19	TMDS data 0/5 mask
	8	Analog vertical synchronization	20	TMDS data 5-
	9	TMDS data 1-	21	TMDS data 5+
	10	TMDS data 1+	22	TMDS clock mask
	11	TMDS data 1/3 mask	23	TMDS clock+
	12	TMDS data 3-	24	TMDS clock-
	C1	Analog vertical synchronization	C4	Analog horizontal synchronization
	C2	Analog green	C5	AGND (RGB circuit)
	C3	Analog blue	-	-

Note

It is recommended to use a standard DVI-D cable. If your display does not provide a DVI-D interface, you can use a DVI to VGA converter.

4.6 USB Interface

The controller provides four USB ports: two USB2.0 ports (③ and ④ in the figure below), and two USB3.0 ports (① and ② in the figure below).




Figure 4-19 USB interface

The specifications of the USB ports are as follows:

Item	USB2.0	USB3.0
Max. communication rate	480Mbps	5.0Gbps
Max. output current at 5 V	500 mA	900 mA
Max. communication distance	5 m	3 m
Isolation	Not supported	Not supported

Note

- For industrial applications, select industry-level USB devices to ensure reliability.
- To prevent interference, avoid long distance connection and run the cable according to the routing specifications.
- If interference cannot be removed, install a magnetic ring at both ends of the communication cable to filter the interference.

4.7 Cable Selection and Preparation

4.7.1 Cable Selection

Applicable Signal	Material Name	Applicable Cable Diameter	
		MM ²	AWG
Power signal cable	Pin type lug	0.8-2.5	20-10
User signal cable	Pin type lug	0.2-1.5	24-16
Grounding cable	Tubular lug	≥ 2	≤ 14
Ethernet cable	-	-	-

4.7.2 Cable Preparation Requirements

1 Cable with pin type lug

Prepare a cable with a pin type lug:

1. Strip back the wire outer coating by 6 mm.
2. Pass the cable through the tube of proper wire size.
3. Insert the exposed conductor into the hole of the cable lug, and then crimp it with recommended crimping tool.
4. Use a heat-shrinkable tube (Φ3) of 20 mm long to wrap the copper tube of a cable lug and then perform thermal shrinkage.
5. Insert the cable lug into the terminal block.




Figure 4-20 Preparing cable with pin type lug

2 Cable with tubular lug

Preparing a cable with a tubular lug:

1. Remove the insulation of the cable so that a length of 6 mm of the conductor is exposed. Then pass the cable through a cable marking tube.
2. Insert the exposed conductor into the hole of the cable lug, and then crimp it with recommended crimping tool.
3. Pass the cable lug through the terminal block and tighten it with a screwdriver. The maximum tightening torque is $0.45 \text{ N} \cdot \text{m}$.





Figure 4-21 Preparing cable with tubular lug

For the 2*6-pin dual-row connector used for I/O and communication, the requirements are as follows:



Category	Terminal Size	Length of Metal Part L2	Strip Length
Tubular end with sheath (max. conductor OD: 2.6 mm)	1.00 mm ² [H1.0/18D]	12 mm	15 mm
	0.75 mm ² [H0.75/18D]	12 mm	14 mm
	0.50 mm ² [H0.5/16D]	10 mm	12 mm
	0.34 mm ² [H0.34/12D]	8 mm	10 mm
	0.25 mm ² [H0.25/12D]	8 mm	10 mm
Naked end	1.50 mm ² [H1.5/10D]	10 mm	10 mm
Tubular end with sheath (crimped with two conductors)	2 x 0.20 mm ² [H0.5/16D]	10 mm	12 mm
	2 x 0.34 mm ² [H0.5/16D]	12 mm	15 mm

5 Operation Instructions

5.1 Power-On

5.1.1 Safety Precautions

Safety Precautions
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">  Warning </div> <ul style="list-style-type: none"> • Do not touch the terminal when the power is on. Failure to comply may result in electric shock. • Do not disassemble this product. Especially when the power is on or shortly after the power is turned off. Because high voltage can be generated by the voltage boost inside the power supply, which may cause electric shock. In addition, internal sharp parts and high temperatures may cause injuries.
<div style="border: 1px solid black; padding: 5px;">  Caution </div> <p>It takes about 15 to 25 or 70 to 80 seconds from power-on to entering the operating mode. During this period, the output remains OFF or a value corresponding to module/slave settings, and external communication is unavailable. To avoid malfunction of external devices, you should construct a fail-safe circuit with "Output during Operation" of the power supply unit.</p>

5.1.2 PLC Startup

The PLC becomes operable after the following time since power-on. Before the PLC enters the operating status, the RUN LED indicator is off.

PLC startup time after power-on:

- If the programming port (enp1s0) is set to a static IP address, it takes about 15 to 25 seconds for the PLC to enter operating mode.
- If the programming port (enp1s0) is set to a DHCP-assigned address, but no DHCP server or network connection is available, it takes about 70 to 80 seconds for the PLC to enter operating mode.


Note

1. Some EtherCAT slaves allow you to set the maximum waiting time (1s to 200s), but the PLC only becomes operable when the EtherCAT master starts operation, regardless of the waiting time.
 2. The EtherCAT master function module treats a slave that has not been activated within the maximum waiting time as an error.
-

5.1.3 Operations when PLC becomes Operable

If there is an app when the PLC becomes operable, the PLC enters operating status immediately. You can also change the default setting to make the PLC to enter stop status instead. If the operation mode

of the user program (App) is "NO-APP" when the power is on, the PLC immediately enters No-APP state.



5.2 Power-Off

5.2.1 Safety Precautions

Safety Precautions	
	Warning
<ul style="list-style-type: none"> The AC800 series controller will continue to operate normally for a certain period of time when an instantaneous power failure occurs, so it may receive error signals from external devices affected by the instantaneous power failure. Take fail-safe measures externally and monitor the power supply voltage on the external device side as necessary, and also take safety measures in the user program. 	

As shown in the following table, the power-off detection time may vary depending on the power supply type.

Power-off voltage

UPS code	Power supply input	Power-off voltage
72030025	24 VDC	Below 22.5 V


Power supply type

Power supply type	Power-off detection time
Non-UPS	Power off immediately
UPS	15 ms


5.2.2 Operations at Power-Off

When the power is off due to exceeding the following power-off detection time, the user program will be terminated. The PLC will be stopped when the process after power-off detection are performed (described below).

Power supply type	Instantaneous power-off time at power-off
Non-UPS	Power off immediately
UPS	Above 15 ms



After the power-off detection time, even if the voltage is reset, the PLC still stops running, as shown in the following figure:




The times in the above figure are described as follows:

Item	Description
Power-off detection time	The period from the time when the power supply voltage drops to the time when the UPS power supply detects that the power supply is off. Before it is determined that the power supply is off, the PLC continues to operate.
Power-off detection delay	The period from the time when the UPS detects that the power supply is off to the time when the PLC starts to process after power-off detection.

5.2.3 Operations at Instantaneous Power-off

When an instantaneous power-off occurs within the following time, the user program will continue to execute.

Power supply type	Time before Power-off
Non-UPS	Power off immediately
UPS	Below 15 ms




5.2.4 Processing after Power-off Detection

If the UPS determines that the power supply is off, it notifies the PLC through I/O to perform the following processes before the PLC stops.

Item		Contents
Processing	Transferring user program (Including online editing)	The transfer is terminated. The controller will be in a no-app state at the next power-on, waiting for the user application program to be downloaded.
	Executing user program	The instruction execution is terminated, and the data is saved in the hard drive via power failure retention.

5.3 Display

5.3.1 Menus



After the PLC is turned on, the BIOS starts and the main page, which includes the Inovance logo and self-test codes, displays.

- If no error occurs, you will see the programming interface page.
- If any error occurs, the error code and detailed error information will display (see section [“8.1 Appendix 1 Process Codes and Error Codes During BIOS Startup”](#) on page 60 for details).


Programming interface page: Displays network information for the programming port (Port A, Ethernet). Use this information to establish a connection to Port A for PLC configuration, program downloads, and other operations. Press "Enter" or wait 30 seconds, to return to the main page.

Note

To prevent endless loop caused by improper programming, you can force the application program not to run at next PLC startup by pressing the combination key "Back" + "Enter", +, in the programming interface page. (see section [“8.2 Appendix 2 Controller Related Error Codes”](#) on page 62 for details).

5.3.2 Main Page


The main page is the most frequently used page when the PLC is running. It is used to display the current status parameters of the PLC, including the application running status (such as "APP1 RUN"), the total CPU occupancy rate, temperature, the operation duration and the current system language.



You can check the running status of multiple applications by pressing the "Up" and "Down" keys.

- Long press the Enter key for 3 seconds to switch the system language
- Press Enter to enter the "Main Menu" interface

Note: Through "Main Menu"->"Performance", you can also view the individual occupancy rate of each CPU core and memory occupancy (see section "4 Performance" in "5.3.3 Main Menu" on page 46 for details).



5.3.3 Main Menu

1 Info

The "Info" menu provides basic information such as PLC related version numbers and the CPU model, as well as information about each network port:

1. Basic Information

Category	Description	Display
SysSW	Board software version	<div style="border: 1px solid black; padding: 5px;"> <p>SysSW: 1.10.40.0</p> <p>LCDSW: 1.0.20.0</p> <p>BIOS: 5.12.0.3</p> <p>CPU: i5- 6200u</p> </div>
LCDSW	Display software version	
BIOS	BIOS version	
CPU	CPU Model	

2. Network port information


Network port screenshot	Description	Network port information	Physical address ^[Note]	Remark
LAN A	Ethernet	<div style="border: 1px solid black; padding: 5px;"> Port A Info 192.168.153.122 255.255.255.0 192.168.153.1 </div>	<div style="border: 1px solid black; padding: 5px;"> 1. ADDEAF3C59FD 2. DDE529CBEE4C 3. FCF2CD77ACB2 4. E2368ADEC69F </div>	Factory recovery is supported. See "2 Settings (5)" in section "5.3.3 Main Menu" on page 46 for details.
LAN B				-
LAN C	EtherCAT			-
LAN D				-

Note: The physical address of each network port can be viewed through "Network Port MAC".

2 Settings

1. Password

The Settings menu contains high permission level operations on the PLC. If no password is set through the InoProShop tool (see Help Document in InoProShop for details) or if the password is set as "0000" (regarded as no password), you can directly access the Settings menu to perform corresponding operations. If you have set a valid 4-digit password through the InoProShop tool, you will be prompted to enter the password when entering the submenu of Settings.



Password page

- After you enter the password page, the first digit of the password, which is 0, flashes. Press the Up/ Down keys to cycle through digits from 0 to 9.
- When you get the desired digit, press "Enter" to input the digit.
- Every time one digit is input, the focus will move to the next input field. Enter the digits in sequence to input the whole password.
- You cannot backspace any input digit because no such function is provided. You have to press the Back key to return to the previous menu, and then press the Enter key to re-enter the password page.

Entering the password

- The digit that you are currently inputting will be displayed in plain text. After pressing Enter, the digits will be ciphered.
- After you input the last digit and press Enter, if the password is wrong, all digits will be cleared you have to re-enter the password.
- If the password is correct, press Enter to enter the next menu.

Note

Within 5 minutes after entering the correct password, you will enter the menu that requires permission without prompting for the password again. After 5 minutes or when the password is changed, you will be prompted to enter the password again when you re-enter the menu that requires permission.


2. System upgrade

You can use the System Upgrade menu to upgrade the PLC system. After the upgrade is successful, you can view the current version information through Information-Basic Information menu.

Insert the USB drive containing the system upgrade package into any USB interface of the PLC, and select the System Upgrade menu to upgrade the system as instructed. When the upgrade progress reaches 100%, the PLC restarts. If any error occurs during upgrade, an "upgrade failed" message displays.

Requirements for upgrade

- a. A USB drive containing the system upgrade package provided by the manufacturer.
- b. The upgrade package is in the root directory of the USB drive (if there are multiple upgrade packages, only the upgrade package in the root directory is valid).



Note

1. The system will be upgrade in an exclusive mode, that is, all key operations are temporarily disabled until the upgrade is successful or fails.
2. USB upgrade and InoProShop tool upgrade cannot be performed at the same time. If you start the system upgrade through the USB drive first, and then perform the upgrade again with the InoProShop tool, the tool will prompt "Firmware is being updated". If you start the system upgrade through the InoProShop tool first, and then perform the upgrade again through the USB drive, the display will prompt "Software tool is upgrading the system, please try again later."


3. Download USB program

You can use the Download USB Program menu to download the application package in the USB drive and replace the application in PLC.

Insert the USB drive containing the application package into any USB interface of the PLC, and enter the "Download USB program" menu to download the program as instructed. When the download progress reaches 100%, a "download successful" message displays. If any error occurs during upgrade, a "download failed" message displays.

Requirements for download

- a. The USB drive contains the application package named Application.userprg, which is packaged and generated by InoProShop.
- b. The application package is in the root directory of the USB drive (if there are multiple packages, only the package in the root directory is valid).




Note

1. The program download is performed in an exclusive mode, that is, all key operations are temporarily disabled until the download is successful or fails.
 2. USB download and InoProShop tool download cannot be performed at the same time. If you download the program through a USB drive first, and then perform the download again with the InoProShop tool, the tool will prompt "USB drive is updating firmware or downloading application program". If you download the program through InoProShop first, and then perform the download again through the USB drive, the display will prompt "Software tool is downloading program, please try again later".
-

4. Program status at startup

You can use the Program Status at Startup menu to set the status of the application program at the next PLC startup (the factory default is "1. Run program at startup").

Select this menu to enter the setting page. "<" indicates the default startup status of the application program set in the PLC. Use the Up and Down keys to select the status, and press the Enter key to confirm the selection. After the setting is completed, "<" will move to the selected item. If there are multiple applications in the PLC, this operation will take effect for all of them.



Error handling


If any error occurs, the screen will show the error code in most cases. See section 5.3.3.3 Errors for details. If the screen does not show the error code and does not respond to any key operation, the PC may be freezing due to, for example, an infinite loop in the application. You can terminate and delete the application.

Operating procedure:

- a. 1. Press Back+Enter for 5s at the startup screen to set "Program status at startup" to "Stop".
- b. 2. Reset the equipment through InoProShop (see Medium Size PLC Programming Software User Guide) and download the correct application.

5. Reset network ports A and B

You can use Reset Network Ports A and B to restore the network ports A and B to the default IP or dynamic IP (as shown in the figure below). After the restoration is done, by setting the PC to the same network segment as the PLC, you can connect to and operate the PLC through a cable (For example, you can connect to port A by setting the PC to 192.168.1.X, and to port B by setting PC to 192.168.2.X).




The network port information is shown in following table:

Network port screenprint	LAN A	LAN B
Ex-factory information	<div style="border: 1px solid black; padding: 5px;"> Port A Info 192.168.1.88 255.255.255.0 192.168.11 </div>	<div style="border: 1px solid black; padding: 5px;"> Port B Info 192.168.2.88 255.255.255.0 0. 0. 0. 0 </div>


6. Restore backup program

You can use Restore Backup Program to restore the APP to the latest backup program, no matter if it is online-modified or downloaded. The latest one is determined according to the modification time. The detailed procedure is as follows. After the restoration is done, restart the controller so that the latest back program can be applied to the APP.




7. UPS setting

You can use the UPS Settings menu to set the UPS power-off time and power-off operation. You can set the power-off time to 200 ms, 400 ms, 600 ms, or 800 ms, and set the power-off operation to restart or shutdown.



8. Restore default settings


You can use the Restore Default Settings menu to restore the PLC to default settings, clear user password and application programs.



3 Errors

Startup error

After the PLC starts, it performs the BIOS self-test and displays the Inovance logo and self-test codes. If an error is detected during the self-test, you will be led to the error page, which shows the error code and detailed information (for details, see Appendix I).



If an error occurs during startup, see Appendix I or contact the manufacturer for support.

BIOS error

The display stays on the startup interface and displays the Inovance logo, which is caused by two errors that may occur during BIOS startup:

- After the self-test codes are sent, the system fails to be loaded. The display stays on the startup interface, showing the Inovance logo and self-test codes. After two minutes, the "Er.A1 Failed to switch BIOS to OS" message displays. You can return to the startup interface by pressing the Back key.
- No self-test code is sent when the BIOS starts. The display stays on the startup interface, showing the Inovance logo and self-test codes. After one minute, the "Er.A2 No BIOS data was received" message displays to warn the user that the BIOS self-test codes have not been sent. You can return to the startup interface by pressing the Back key.

Program and system error

- Error window

When the display stays on the programming interface page or the main page, if an error occurs in the program or system, the screen will show the error code and detailed information. You can return to the previous interface through the Back key. If there are multiple errors, you can use the Up and Down keys to view the full information of an error, and use the Enter key to display the next error.


Note

Special error Er.22 indicates that the communication between the display and the PLC is disconnected. It is due to system crash or communication timeout between the screen and board daemon process caused by an endless loop in an application program. In this case, the display cannot obtain and display PLC information, and cannot be operated by keys. The user can restart the computer and use the key combination Back+Enter on the programming interface page to forcibly modify the APP's next startup status to "stop". When the error is removed, the error information will be cleared.

Er. 22
System:Comm.Time
out between PLC
& Panel

Errors menu

You can view the detailed information of current errors of the PLC through the Errors menu. If there are multiple errors, you can use the "Up" and "Down" keys to view the full information of an error, and use the Enter key to switch to the next error (for details, see ["8.1 Appendix 1 Process Codes and Error Codes During BIOS Startup" on page 60](#)).



If the PLC is free from any error, it will display "NO ERROR!!".

NO ERROR !!

4 Performance

You can use the Performance menu to view the status parameters related to PLC performance, including the CPU core occupancy rate and memory occupancy rate.

CPU0: 23%
CPU1: 10%
MEM: 30%

5.3.4 Page Switchover

When you switch pages on the display panel:


1. The screen will automatically turn off if there is no key operation for 15 minutes (the screen will not turn off when there is an error window). When the screen is off, press any key to wake up the screen.
2. The programming interface page displays for 30 seconds before switching to the active page.
3. Apart from the programming interface page and error page, if you stay on a page for 2 minutes without pressing any key, the screen will switch to the active page.
4. When you insert a USB drive and it is correctly recognized by the system, the display will directly switch to the Settings menu, which is convenient for further operations. However, this does not apply to an interactive page (a page related to upgrade, download, password input, and network port recovery).

5.4 System Upgrade

The PLC system can be upgraded in the following two ways.

1. InoProShop

You can connect to the PLC with the InoProShop tool and select the PLC firmware upgrade package and accessory firmware upgrade package provided by the manufacturer to upgrade the PLC (see InoProShop User Guide for details).



2. USB drive

You can upgrade the PLC by inserting a USB flash drive on the PLC and carry out the upgrade procedure on the display (see (3) Download USB program in 2 Settings in section 5.3.2).

6 Programming and Debugging

For the programming and debugging process, see *Medium-Sized PLC Programming Software User Guide*, *Medium-Sized PLC Programming Guide (Motion Control)*, and *Medium-Sized PLC Programming Instructions*.

7 Maintenance

7.1 Periodical Maintenance and Inspection

Regular Checklist

No.	Item	Description	Criteria	Process
1	Power supply	Measure the power terminal block and check that the voltage change is within the allowed range.	24 VDC (-20% to +20%)	Use a multimeter to measure the terminals, and control the supply voltage within the allowable range.
2	Ambient environment	Check that the ambient temperature is suitable (when the controller is in a cabinet, the temperature in the cabinet is the ambient temperature).	-5°C to 55°C	Use a thermometer to measure the ambient temperature and control the ambient temperature within the range of 0°C to +55°C.
		Check that the ambient humidity is suitable (when used inside the cabinet, the cabinet humidity is considered the ambient humidity).	10% RH to 90% RH, without condensation	Use a hygrometer to measure the ambient humidity control the ambient humidity within 10% to 90% RH. If the temperature changes drastically, check for condensation.
		Direct sunlight	Not allowed	Provide a shelter.
		Dust, dirt, salt, and iron filings	Not allowed	Remove them and provide a shelter.
		Droplets of water, oil, and chemicals	Not allowed	Remove them and provide a shelter.
		Corrosive gas or flammable gas	Not allowed	Use an odor or gas sensor for detection.
		Vibration or shock to the controller	The vibration and shock resistance should meet relevant requirements.	Install cushioning materials for vibration and shock resistance.
Interference sources	Not allowed	Keep the controller away from any interference sources or take shielding measures.		
3	Installation and wiring	Check that cable connectors are fully inserted and locked.	Looseness is not allowed.	Fully insert the connector and lock it with screws.
		Check that external wiring screws are securely fastened.	Looseness is not allowed.	Use a Phillips screwdriver to tighten the screws.
		Check that external wiring terminals are properly distanced.	Ensure a proper distance between terminals.	Check the distance visually and correct any improper distance.
		Check for broken external cables.	Broken external cables are not allowed.	Check cables visually and replace broken cables (if any).

No.	Item	Description	Criteria	Process
4	Real-time clock battery (button battery)	Check that the shelf life or service life does not expire.	No "battery voltage low" alarm is displayed on the controller.	The shelf life of the battery at 25°C is 5 years, and its service life is generally 0.75 to 5 years, depending on the model and ambient temperature. If this predefined period is exceeded, replace the battery no matter if it can still work normally or not. For the replacement method, see section "3.4 Installation and Removal of the Battery" on page 23.
5	Cooling fan	Check that the shelf life or service life does not expire.	No "Fan is abnormal" alarm on the controller.	The design life of the fan at 40°C is 70,000 hours, and its service life varies with the ambient temperature. If the predefined period is exceeded, replace the fan no matter if it can still work normally or not. For the replacement method, see section "3.3 Installation and Removal of the Fan" on page 23.

Tools needed

- Phillips screwdriver
- Multimeter or digital meter
- Industrial alcohol and cotton cloth
- Pliers

Measuring instruments required for different occasions

- Oscilloscope
- Thermometer, humidity meter

7.2 Maintenance of the Battery

Purpose of the battery


A battery is required for the RTC timing of the clock in the controller and for keeping the CMOS data when the power is off. If the battery is not installed or the battery is depleted, the clock will stop timing, and the BIOS CMOS data will be lost when the power is off.

Battery life and replacement interval

The actual life of the battery is related to the application scenario of the controller. The curve below shows the longest life and is for reference only.

When the controller prompts that the battery is abnormal, replace the battery in time to ensure that the clock function of the controller is normal.

When a time deviation is found, check the battery voltage and replace the battery in time.




7.3 Maintenance of the Fan

Purpose of the fan

If the temperature in the controller reaches or exceeds the set temperature, the fan will automatically start to cool down the controller. When the temperature of the controller drops below the fan stop threshold, the fan will stop.

Name	Stop temperature T_o	Start temperature limit T_s	Upper temperature limit T_f
Temperature threshold	40°C	45°C	75°C



Fan life and replacement interval

Code	Model	Fan service life
98050167	AC810-FAN1	70,000 hours


When the controller prompts that the fan is abnormal, replace the fan in time to ensure heat dissipation of the controller.

8 Appendix


8.1 Appendix 1 Process Codes and Error Codes During BIOS Startup

Note: BIOS process coding and error coding are independent of other error coding of the controller.

1. The following figure illustrates display of a BIOS process code:



2. The following figure illustrates display of a BIOS error code:



BIOS Code	Error Message
Process Code	
0x15	Pre-memory North Bridge initialization is started
0x19	Pre-memory South Bridge initialization is started
0x32	CPU post-memory initialization is started
0x3B	Post-Memory South Bridge initialization is started
0x4F	DXE IPL is started
0x60	DXE Core is started
0x61	NVRAM initialization
0x62	Installation of the South Bridge Runtime Services
0x69	North Bridge DXE initialization is started
0x70	South Bridge DXE initialization is started
0x72	South Bridge devices initialization
0x78	ACPI module initialization
0x79	CSM initialization
0x90	Boot Device Selection (BDS) phase is started
0x91	Driver connecting is started
0x92	PCI Bus initialization is started
0x93	PCI Bus Hot Plug Controller Initialization
0x94	PCI Bus Enumeration
0x95	PCI Bus Request Resources
0x96	PCI Bus Assign Resources


BIOS Code	Error Message
0x97	Console Output devices connect
0x98	Console input devices connect
0x99	Super IO Initialization
0x9A	USB initialization is started
0x9C	USB Detect
0x9D	USB Enable
0xA0	IDE initialization is started
0xA2	IDE Detect
0xAD	Ready To Boot event
0xAE	Legacy Boot event
0xB2	Legacy Option ROM Initialization
0xB4	USB hot plug
Error code (When a BIOS error occurs, restart the device; If the error persists, contact the manufacturer.)	
0x0E	Microcode not found
0x0F	Microcode not loaded
0x50	Memory initialization error. Invalid memory type or incompatible memory speed
0x51	Memory initialization error. SPD reading has failed
0x52	Memory initialization error. Invalid memory size or memory modules do not match
0x53	Memory initialization error. No usable memory detected
	Note: If the buzzer sounds 6 times during startup, it means that the memory is installed improperly or is not installed. Contact the manufacturer for a solution.
0x54	Unspecified memory initialization error
0x55	Memory not installed
0x56	Invalid CPU type or Speed
0x57	CPU mismatch
0x58	CPU self test failed or possible CPU cache error
0x59	CPU micro-code is not found or micro-code update is failed
0x5A	Internal CPU error
0x5B	reset PPI is not available
0x5C	PEI phase BMC self-test failure
0xAB	Setup Input Wait
0xD0	CPU initialization error
0xD1	North Bridge initialization error
0xD2	South Bridge initialization error
0xD3	Some of the Architectural Protocols are not available
0xD4	PCI resource allocation error. Out of Resources
0xD5	No Space for Legacy Option ROM
0xD6	No Console Output Devices are found
0xD7	No Console Input Devices are found
0xD8	Invalid password
0xD9	Error loading Boot Option (LoadImage returned error)
0xDA	Boot Option is failed (StartImage returned error)
0xDB	Flash update is failed
0xDC	Reset protocol is not available
0xDD	DXE phase BMC self-test failure
0xE8	S3 Resume Failed
0xE9	S3 Resume PPI not Found

BIOS Code	Error Message
0xEA	S3 Resume Boot Script Error
0xEB	S3 OS Wake Error
0xF8	Recovery PPI is not available
0xF9	Recovery capsule is not found
0xFA	Invalid recovery capsule
0xA1	Failed to switch BIOS to OS
0XA2	No BIOS data was received

8.2 Appendix 2 Controller Related Error Codes

Note: The error code IDs for controller-related functions are independent and do not conflict with other error code IDs.

The error code display examples for controller-related functions are shown in the figure below.



Error Code	Error Message	Solution
Serial communication port 0 (Modbus/RTU)		
0x70	Modbus RTU0:Slave address setting error	Set a legal slave address.
0x71	Modbus RTU0:Frame length error	Modify the data frame.
0x72	Modbus RTU0:Illegal data address	Modify it to a legal data address.
0x73	Modbus RTU0:CRC check failed	1 Check that the termination resistor is connected correctly. 2 Optimize wiring, such as eliminating potential interference sources.
0x74	Modbus RTU0:Illegal function	Check the slave commands.
0x75	Modbus RTU0:Communication time out	1 Check that the slave is working properly. 2 Check that the connection is normal. 3 Check that the termination resistor is connected correctly. 4 Optimize wiring, such as eliminating potential interference sources.
0x76	Modbus RTU0:Illegal data value	Check the range of data written by slave.
0x77	Modbus RTU0:Buffer overflow	Reduce communication load.
0x78	Modbus RTU0:Server device failure	Check the slave communication device.
0x79	Modbus RTU0:Serial port setting error	Check that the communication configuration is correct.
Serial communication port 1 (Modbus/RTU)		
0x80	Modbus RTU1:Slave address setting error	Set a legal slave address.
0x81	Modbus RTU1:Frame length error	Modify the data frame.


Error Code	Error Message	Solution
0x82	Modbus RTU1:Illegal data address	Modify it to a legal data address.
0x83	Modbus RTU1:CRC check failed	1 Check that the termination resistor is connected correctly. 2 Optimize wiring, such as eliminating potential interference sources.
0x84	Modbus RTU1:Illegal function	Check the slave commands.
0x85	Modbus RTU1:Communication time out	1 Check that the slave is working properly. 2 Check that the connection is normal. 3 Check that the termination resistor is connected correctly. 4 Optimize wiring, such as eliminating potential interference sources.
0x86	Modbus RTU1:Illegal data value	Check the range of data written by slave.
0x87	Modbus RTU1:Buffer overflow	Reduce communication load.
0x88	Modbus RTU1:Server device failure	Check the slave communication device.
0x89	Modbus RTU1:Serial port setting error	Check that the communication configuration is correct.
Ethernet (Modbus TCP)		
0x90	Modbus TCP:Slave address setting error	Set a legal slave address.
0x91	Modbus TCP:Frame length error	Modify the data frame.
0x92	Modbus TCP:Illegal data address	Modify it to a legal data address.
0x93	Modbus TCP:CRC check failed	1 Check that the termination resistor is connected correctly. 2 Optimize wiring, such as eliminating potential interference sources.
0x94	Modbus TCP:Illegal function	Check the slave commands.
0x95	Modbus TCP:Communication time out	1 Check that the slave is working properly. 2 Check that the connection is normal. 3 Check that the termination resistor is connected correctly. 4 Optimize wiring, such as eliminating potential interference sources.
0x96	Modbus TCP:Illegal data value	Check the range of data written by slave.
0x97	Modbus TCP:Buffer overflow	Reduce communication load.
0x98	Modbus TCP:Server device failure	Check the slave communication device.
0x9A	Modbus TCP:Destination XX is unreachable	1 Check that the slave is working properly. 2 Check that the connection is normal. 3 Check that the master hardware is working properly. 4 Optimize wiring, such as eliminating potential interference sources.
0x9B	Modbus TCP:Protocol identifier error	Check the protocol identifier.
CPU error		
0x21	Runtime crashed	1 Power on again. 2 Contact the agent or Inovance.
0x22	LCD: Communication time out between CPU	
0x24	Battery voltage is too low or battery is in reverse	Replace the battery or check for incorrect installation.
0x25	Fan is broken or not installed	Check for fan malfunction.

Error Code	Error Message	Solution
0x26	Daemon: Communication time out between runtime	1 Correct the application program, restart the PLC, and download and execute the program again. 2 Obtain application run logs through the diagnostic window. 3 Collect log information and analyze it through InoProShopTools.
0x27	Application exception	Check and update the application.
0x28	Bootproject load fail	Program startup abnormal, check and update the application.
0x2E	ProcessorLoad exception	Check the application task configuration.
0x2F	Network open failed	1 Power on again. 2 Contact the agent or Inovance.
Authentication error		
0x23	Authentication failed, please contact the supplier!	1 Power on again. 2 Contact the agent or Inovance.
Memory error		
0x31	Memory init fail	Return the device for repair.
Register error		
0x29	FPGA PCIE offline and online again	1 Record exceptions and provide feedback to our developers. 2 On site analysis of EMC issues.

8.3 Appendix 3 EtherCAT Related Error Codes

Note: The error code IDs for EtherCAT are independent and do not conflict with other error code IDs. The specific error descriptions (in English) will be displayed on the screen.

The error code display examples for EtherCAT-related functions are shown in the figure below.



Error Code	Error Message	Solution
EtherCAT		
0x01	Error: communication lost! check the cables!	<ol style="list-style-type: none"> 1 Check that the network cable between the master and slave is connected properly. 2 Check that the connection to OUT port of the slave is correct. 3 Check that the network cable is connected properly. 4 Check that the network cable connector is wrapped in metal. 5 Check that the network cable meets the specification requirements for Cat5e cables. 6 Check that the device is properly grounded. 7 On the master, set xRestart to TRUE to restart the bus. 8 Power off and restart the PLC and slave.
0x02	Warning: number of slaves has changed or is different to the configuration!	Check if the slave is powered down and if the network cable is disconnected.
0x03	Distributed clock is always same value! Change in and out connector of slave	Check if the reference clock slave is disconnected.
0x04	Network adapter could not be found	<ol style="list-style-type: none"> 1 Check network port configuration. 2 Restart the PLC. 3 Replace the PLC.
0x05	Second Network adapter could not be found	<ol style="list-style-type: none"> 1 Check network port configuration. 2 Restart the PLC. 3 Replace the PLC.
0x06	Second Network adapter uses the MAC-ID as first network adapter	<ol style="list-style-type: none"> 1 Restart the PLC. 2 Replace the PLC.
0x07	Init slaves error: possibly slave missing or no communication at all	<ol style="list-style-type: none"> 1 Check if the network cable connection between the master and slave is down. 2 Check if the network cable connection between slave stations is disconnected, poorly connected, or experiencing hardware failure. 3 Check if the slaves are interconnected at OUT ports. 4 Use EtherCAT scanning function to locate the faulty slave. 5 Power off and restart all slaves.
0x08	VendorID does not match -> All stopped	<ol style="list-style-type: none"> 1 Use EtherCAT scanning function to compare configuration with scanning results. 2 Power off and restart the slave which the master failed to access.
0x09	ProductID does not match -> All stopped	<ol style="list-style-type: none"> 1 Use EtherCAT scanning function to compare configuration with scanning results. 2 Power off and restart the slave which the master failed to access.
0x0A	Read of product or vendor ID not successful, more slaves in config as real?	Use EtherCAT scanning function to compare configuration with scanning results.
0x0B	SDO write error in startup procedure	See the slave device user guide to find the error cause and the solution in "Return Error Code" section.

Error Code	Error Message	Solution
0x0C	SDO timeout in startup procedure	<ol style="list-style-type: none"> 1 Check the network connection status of the slave. 2 Check user programs, reduce the scheduling times of SDO, EOE and SOE function blocks to reduce the communication load.
0x0D	Emergency from device received	See the slave device user guide to find the error cause in "Emergency Event Error Code", "Error Register", and "Manufacturer Custom Error Code" sections.
0x0E	IDN write error in startup procedure	<ol style="list-style-type: none"> 1 See the slave device user guide to find the error cause in "Return Error Code" section. 2 Reconnect the slave to the network.
0x0F	IDN timeout in startup procedure	<ol style="list-style-type: none"> 1 Check the network connection status of the slave. 2 Check user programs to reduce the number and frequency of SDO, EOE, and SOE function blocks.
0x10	Watchdog expired for opmode	<ol style="list-style-type: none"> 1 In the overview interface of EtherCAT master, troubleshoot slaves whose receive error counter value is not equal to 0 and the network cable connection status. 2 Check that the device is properly grounded. 3 Restart EtherCAT master. 4 Replace the slave device.
0x20	Slave alias address duplicate error!	In the EtherCAT scanning interface, reconfigure the alias address of the conflicting slaves. After successful writing, power off and restart the slaves to take effect.
0x21/0x12D	In/out connection error between slaves	<ol style="list-style-type: none"> 1 Connect the OUT port of the slave to the OUT port of another slave. 2 Connect the OUT port of the slave to the master.
0x22	Access slave EEPROM timeout	Power off and restart the slave.
0x30	Continuous frame drop error!	<ol style="list-style-type: none"> 1 Check that the network cable is connected. 2 Replace the network cable. 3 Replace the slave. 4 Add a magnetic ring or replace with a higher-grade network cable.
0x31	Link lost error!	<ol style="list-style-type: none"> 1 Check that the network cable connector is connected properly. 2 Check that the network cable is connected. 3 Replace the network cable.
0x32	Occasion frame drop error!	<ol style="list-style-type: none"> 1 Replace the network cable. 2 Replace the current slave or the previous slave. 3 Add a magnetic ring or replace with a higher-grade network cable.
0x65	Unspecified error	<ol style="list-style-type: none"> 1 Power on again. 2 Contact the agent or Inovance.

Error Code	Error Message	Solution
0x66	No memory	1 Power on again. 2 Contact the agent or Inovance.
0x6A	Firmware and EEPROM does not match	1 Power on again. 2 Contact the agent or Inovance.
0x6B	Firmware update not successful	Check the master state machine switchover request process; cross-level requests to change the slave state machine are prohibited.
0x75	Invalid requested state change	Check the master state machine switchover request process; cross-level requests to change the slave state machine are prohibited.
0x76	Unknown requested state	Check the master state machine switchover request process; cross-level requests to change the slave state machine are prohibited.
0x77	Bootstrap not supported	1 Power on again. 2 Contact the agent or Inovance.
0x78	No valid firmware	1 Power on again. 2 Contact the agent or Inovance.
0x79	Invalid mailbox configuration	1 Power on again. 2 Contact the agent or Inovance.
0x7A	Invalid mailbox configuration	1 Power on again. 2 Contact the agent or Inovance.
0x7B	Invalid sync manager configuration	1 Power on again. 2 Contact the agent or Inovance.
0x7C	No valid inputs available	Reconfigure slave input PDO data.
0x7D	No valid outputs	Reconfigure slave output PDO data.
0x7E	Synchronization error	1 Power on again. 2 Contact the agent or Inovance.
0x7F	Sync manager watchdog	1 Power on again. 2 Contact the agent or Inovance.
0x80	Invalid Sync Manager Types	1 Power on again. 2 Contact the agent or Inovance.
0x81	Invalid Output Configuration	The slave does not support the configuration quantity of output PDO object dictionary. Adjust the output PDO.
0x82	Invalid Input Configuration	The slave does not support the configuration quantity of output PDO object dictionary. Adjust the input PDO.
0x83	Invalid Watchdog Configuration	1 Power on again. 2 Contact the agent or Inovance.
0x84	Slave needs cold star	1 Power on again. 2 Contact the agent or Inovance.
0x85	Slave needs INIT	1 Power on again. 2 Contact the agent or Inovance.

Error Code	Error Message	Solution
0x86	Slave needs PREOP	1 Power on again. 2 Contact the agent or Inovance.
0x87	Slave needs SAFEOP	1 Power on again. 2 Contact the agent or Inovance.
0x88	Invalid input mapping	1 Check if input PDO object dictionary entries do not match the slave firmware program. 2 Check if Vendor ID verification is disabled in slave configuration. 3 Check if Product ID is inconsistent between slave configuration and actual hardware.
0x89	Invalid output mapping	1 Check if output PDO object dictionary entries do not match the slave firmware program. 2 Check if Vendor ID verification is disabled in slave configuration. 3 Check if Product ID is inconsistent between slave configuration and actual hardware.
0x8A	Inconsistent settings	1 Power on again. 2 Contact the agent or Inovance.
0x8B	Free-Run not supported	1 Power on again. 2 Contact the agent or Inovance.
0x8C	Synchronization not supported	1 Power on again. 2 Contact the agent or Inovance.
0x8D	Free-Run needs 3 buffer mode	1 Power on again. 2 Contact the agent or Inovance.
0x8E	Backgroundwatchdog	1 Power on again. 2 Contact the agent or Inovance.
0x8F	No valid inputs and outputs	1 Power on again. 2 Contact the agent or Inovance.
0x90	Fatal Sync error	1 Power on again. 2 Contact the agent or Inovance.
0x91	No Sync error	1 Power on again. 2 Contact the agent or Inovance.
0x92	Cycle Time too small	1 Power on again. 2 Contact the agent or Inovance.
0x94	Invalid DC SYNCH Configuration	1 Power on again. 2 Contact the agent or Inovance.
0x95	Invalid DC Latch Configuration	1 Power on again. 2 Contact the agent or Inovance.

Error Code	Error Message	Solution
0x96	PLL Error	1 The slave reconnects after network disconnection, and the error is automatically reset. 2 The bus cycle is unreasonable, recommended parameters: 125 μ s–8000 μ s; the master synchronization offset is unreasonable, adjustment range: -50% to +50%.
0x97	Invalid DC IO Error	1 Power on again. 2 Contact the agent or Inovance.
0x98	Invalid DC Timeout Error	1 Power on again. 2 Contact the agent or Inovance.
0x99	DC invalid Sync Cycle Time	1 Power on again. 2 Contact the agent or Inovance.
0x9A	DC Sync0 Cycle Time	1 Power on again. 2 Contact the agent or Inovance.
0x9B	DC Sync1 Cycle Time	1 Power on again. 2 Contact the agent or Inovance.
0xA5	MBX AOE	1 Power on again. 2 Contact the agent or Inovance.
0xA6	MBX EOE	1 Power on again. 2 Contact the agent or Inovance.
0xA7	MBX_COE	1 Power on again. 2 Contact the agent or Inovance.
0xA8	MBX_FOE	1 Power on again. 2 Contact the agent or Inovance.
0xA9	MBX SOE	1 Power on again. 2 Contact the agent or Inovance.
0xB3	MBX_VOE	1 Power on again. 2 Contact the agent or Inovance.
0xB4	EEPROM no access	Change the EEPROM access address or data length.
0xB5	EEPROM error	1 Power on again. 2 Contact the agent or Inovance.
0xB6	External hardware not ready	1 Power on again. 2 Contact the agent or Inovance.
0xC4	Slave restarted locally	1 Power on again. 2 Contact the agent or Inovance.
0xD4	Detected Module and Configured does not match	Use EtherCAT scanning function to compare the project configuration with scanning results.



19010617B07

Copyright © Shenzhen Inovance Technology Co., Ltd.

Shenzhen Inovance Technology Co., Ltd.

www.inovance.com

Suzhou Inovance Technology Co., Ltd.

www.inovance.com

Add.: Inovance Headquarters Tower, High-tech Industrial Park,
Guanlan Street, Longhua New District,
Shenzhen 518000, P.R. China

Tel: (0755) 2979 9595 Fax: (0755) 2961 9897

Add.: No.52, Tian E Dang Road, Wuzhong District,
Suzhou 215104, P.R. China

Tel: (0512) 6637 6666 Fax: (0512) 6285 6720